


E-SERIES



- A - 1/4" Nylon Locknuts (2)
 - B - Mounting Bracket (2)
 - C - Compression Spacers (2)
 - D - Light Bar
- Also Included - Wiring Harness



DIAGRAM A



Register your product's warranty at RigidIndustries.com/Warranty
For warranty concerns email warranty@RigidIndustries.com or call us at 480-655-0100.

WARRANTY INFORMATION

Rigid Industries warrants that the product will be free from defects in material and workmanship. Warranty periods vary per product type. In cases where repair of product is necessary, Rigid Industries prefers whenever possible to handle claims directly. All warranties are non-transferable.

Warranty Periods:

- All LED Light bars – Limited Lifetime
- Accessories and Mounts – 2 years
- Flashlights – 1 year
- Batteries – 90 days
- HID Replacement Kits – 2 years

Warranty Coverage:

Return Material Authorization numbers must be clearly marked on outside of packaging and all accompanying documentation. Proof of purchase is required to validate warranty and is valid from the original date of purchase. Call for RMA.

In cases where product is faulty:

With in 60 days – Replacement items may be offered. Rigid Industries will send replacements to the customer and cover return shipping of defective product.
From 60 days to 1 year - The customer is responsible for shipping charges to Rigid Industries for repair of the products. Rigid Industries will cover all parts, labor and return shipping.
After 1 year – The customer is responsible for all shipping charges to Rigid Industries for repair of the products and labor. Rigid Industries will cover all parts and return shipping.

All of the following will immediately void all warranties:

- Customer negligence – The customer has modified the light and/or is not using it for the recommend application.
- Customer abuse – Damage to the light beyond normal wear and tear.
- Repair work done by unauthorized personnel without Rigid Industries' approval.
- **If the light has been opened** or any screws have been removed.

** It is up to Rigid Industries' discretion on how to handle a claim, refund, or warranty. All of the policies above are subject to change without prior notice. **



RIGID INDUSTRIES PRODUCT INSTRUCTIONS

E-SERIES



SR-SERIES



YOUR PRODUCT INTRODUCTION AND INSTALLATION GUIDE.
WWW.RIGIDINDUSTRIES.COM

SR-SERIES




- A - 1/4" Nylon Locknuts (2)
 - B - Short Mounting Bracket (2)
 - C - Tall Mounting Bracket (2)
 - D - Compression Spacers (2 - already installed)
 - E - Light Bar
- Also Included - Wiring Harness



DIAGRAM B

E-SERIES



- A - 1/4" Nylon Locknuts (2)
 - B - Mounting Bracket (2)
 - C - Compression Spacers (2)
 - D - Light Bar
- Also Included - Wiring Harness



DIAGRAM A



Register your product's warranty at RigidIndustries.com/Warranty
For warranty concerns email warranty@RigidIndustries.com or call us at 480-655-0100.

WARRANTY INFORMATION

Rigid Industries warrants that the product will be free from defects in material and workmanship. Warranty periods vary per product type. In cases where warranty and repair of product is necessary, Rigid Industries prefers whenever possible to handle claims directly. All warranties are non-transferable.

Warranty Periods:

- All LED Light bars – Limited Lifetime
- Accessories and Mounts – 2 years
- Flashlights – 1 year
- Batteries – 90 days
- HID Replacement Kits – 2 years

Warranty Coverage:

Return Material Authorization numbers must be clearly marked on outside of packaging and all accompanying documentation. Proof of purchase is required to validate warranty and is valid from the original date of purchase. Call for RMA.

In cases where product is faulty:

With in 60 days – Replacements items may be offered. Rigid Industries will send replacements to the customer and cover return shipping of defective product.
From 60 days to 1 year - The customer is responsible for shipping charges to Rigid Industries for repair of the products. Rigid Industries will cover all parts, labor and return shipping.
After 1 year – The customer is responsible for all shipping charges to Rigid Industries for repair of the products and labor. Rigid Industries will cover all parts and return shipping.

All of the following will immediately void all warranties:

- Customer negligence – The customer has modified the light and/or is not using it for the recommend application.
- Customer abuse – Damage to the light beyond normal wear and tear.
- Repair work done by unauthorized personnel without Rigid Industries' approval.
- **If the light has been opened** or any screws have been removed.

** It is up to Rigid Industries' discretion on how to handle a claim, refund, or warranty. All of the policies above are subject to change without prior notice. **



RIGID INDUSTRIES PRODUCT INSTRUCTIONS

E-SERIES




SR-SERIES



YOUR PRODUCT INTRODUCTION AND INSTALLATION GUIDE.
WWW.RIGIDINDUSTRIES.COM

SR-SERIES



- A - 1/4" Nylon Locknuts (2)
 - B - Short Mounting Bracket (2)
 - C - Tall Mounting Bracket (2)
 - D - Compression Spacers (2 - already installed)
 - E - Light Bar
- Also Included - Wiring Harness



DIAGRAM B


Congratulations on your purchase of Rigid Lights!

Rigid Industries' patented optics allow our lights to throw more light, more accurately than any other competitor. Combine that with Rigid's cutting edge electronics and extrusion design and the choice is clear! Don't forget about our limited lifetime warranty!

1. Insert mounting brackets onto light as shown in Diagram A or B. Secure hardware to a snug position and mount your light into desired location.
2. Disconnect the negative battery cable from the battery.
3. Attach red terminal eyelet to battery positive or any 12V DC source. Secure black terminal to suitable ground or battery negative. Route harness to desired switch and mounting locations, secure with zip ties. Beware of sharp edges, abrasive surfaces and heat sources when wiring.
4. When installing Rigid lights on a 24V DC system be sure to use a 24V relay. When installing multiple lights be sure to have adequate fusing.
5. Finally, test lights to ensure proper function and then secure mounting hardware according to your desired light beam angle.

For technical support call us at 480-655-0100.

*Rigid Industries always recommends installation from an industry professional. Be sure to read warranty information on back.



COVERS & ACCESSORIES AVAILABLE!



Visit RigidIndustries.com for more accessories!


Congratulations on your purchase of Rigid Lights!

Rigid Industries' patented optics allow our lights to throw more light, more accurately than any other competitor. Combine that with Rigid's cutting edge electronics and extrusion design and the choice is clear! Don't forget about our limited lifetime warranty!

1. Insert mounting brackets onto light as shown in Diagram A or B. Secure hardware to a snug position and mount your light into desired location.
2. Disconnect the negative battery cable from the battery.
3. Attach red terminal eyelet to battery positive or any 12V DC source. Secure black terminal to suitable ground or battery negative. Route harness to desired switch and mounting locations, secure with zip ties. Beware of sharp edges, abrasive surfaces and heat sources when wiring.
4. When installing Rigid lights on a 24V DC system be sure to use a 24V relay. When installing multiple lights be sure to have adequate fusing.
5. Finally, test lights to ensure proper function and then secure mounting hardware according to your desired light beam angle.

For technical support call us at 480-655-0100.

*Rigid Industries always recommends installation from an industry professional. Be sure to read warranty information on back.



COVERS & ACCESSORIES AVAILABLE!



Visit RigidIndustries.com for more accessories!